

# Stainless Steel Washdown Scales

Innovation for making fixed weight food packages

# Yamato

## Multifunctional Digital Platform Scale

# DP-5602



DP-5602 Indicator

The DP-5602 indicator has a lot of useful functions such as Checkweighing (over/under) function judged by 3 color LED indicator and a buzzer, Shortage guidance display for making fixed weight packages, Grading function for sorting items by weight, Gross / Net weight indication, etc. The indicator can also control automatic filling system thanks to 6 set-points.



DP-5602 Desk-top Type



## Options

## FEATURES

### Checkweighing Function

The Over / Accept / Under weight can be judged by 3 color LED indicator and a built-in buzzer.

### Shortage Guidance Display

A Full dot LCD with back light made English literature and sweep bar display possible. It indicates the shortage against the target in work unit (one spoon, half cup, 3 pieces or else ) at fixed weighing function. This reduces a burden of operators and improves work efficiency.

### Grading Function

In addition to the normal grading function, the subtractive grading function is equipped as a standard. This function helps to speed up sorting operation.

As an option, audible judgment is possible.

### Journal Printer (Option)

A built-in Journal Printer, JPS-508 is available as an option.

### USB Memory (Option)

It is possible to save weighing results in CSV format in a USB Memory. Users can save and re-arrange weighing data simply by inserting the USB memory into a PC. It enables you to avoid data transcription and realize labor saving. It also helps analysis of data for improving work process and efficiency.



DP-5602 Small (Separate type)

## SPECIFICATIONS

Model	DP-5602 (Desk-Top)			DP-5602 (Small Size)		
Indicator Model	EDI-562					
Capacity	3 kg	6 kg	15 kg	30 kg	60 kg	150 kg
Division	0.001 kg	0.002 kg	0.005 kg	0.01 kg	0.02 kg	0.05 kg
Tare Max.	3 kg	6 kg	15 kg	30 kg	60 kg	150 kg
Platform Size	350(W) x 300(D) mm			350(W) x 500(D) mm		
Net Weight	10 kg			18 kg		
Operating Temp.	-10°C to 40°C					
Indicator Size	290(W) x 198(H) mm					
Main Display	6 Digits Fluorescent Display / Character size: 32(H) x 14.6(W) mm					
Auxiliary Display	Full Dot LCD with Back Light, 64(H) x 240(W) dots					
Dust/Water Protection	Indicator only: IP66					
Functions	Zero reset, One-touch tare, Preset tare, Checkweighing, Fixed weighing, Grading and Counting					
Power	AC230V +10% to -15% 50/60Hz					
Options	Integrated Pole, Separate Stand Pole, Built-in Journal Printer JPS-508, Bi-directional RS232, Bi-directional RS485, Relay Input/Output, USB Memory, Wireless Communication					

The contents of this catalogue are subject to change without notice.

**Yamato Scale Co., Ltd.**

5-22 Saenba-cho, Akashi 673-8688, Japan  
Tel: +81-78-918-6157 Fax: +81-78-918-5562